


8kg/5kg Combi Clothes Washer Dryer

OFL80D50W

omega



Designed to Enhance
EST. 1981


Introducing your new Combi Clothes Washer Dryer

Before First Use

Before using your appliance for the first time:

- Ensure the appliance is correctly installed as per the installation instructions in your User Manual pages 08–09.
- The transport bolts have been removed from the rear.
- Clean your appliance before first use.
To remove any residual water and to neutralise potential odours from the manufacturing process, we recommend to clean the inner drum by running the “Drum Clean” program.
Do not to put laundry and detergent in the machine when performing the Drum Clean program.
- Please check your laundry care labels and the detergent use instructions before wash.

Dimensions



Details

Product Dimensions (W, D, H mm): 595 × 535 × 850
Warranty Period: 2 Years

Washing & Drying Programs

- | | |
|----------------|---------------------|
| ☰ Personalised | 🕒 Quick 15' / 1h WD |
| 👕 Cotton | 🛡️ Steam Shield |
| 👕 Mix | 🌿 Cotton ECO |
| 👶 Baby | 🌡️ 20° C |
| 🐑 Wool | 👕 Wash & Dry |
| 🧼 Drum Clean | 👕 Auto Dry |
| 🌀 Spin Only | 🕒 Time Dry |

Additional Functions

- | | |
|------------------|-------------------------|
| 🕒 Pre Wash | 🕒 Delay Start |
| 👑 Extra Rinse | WASH TEMP Washing Temp. |
| ⚡ Speed Wash | SPIN SPEED Spin Speed |
| 🌿 Precise Purify | RELOAD Reload |
| ☀️ Dry Level | 🔒 Child Lock. |

For a detailed explanation on each program and function, and also detailed operation instructions, refer to your User Manual Pages 11–17.

Support

Telephone: 1300 11 HELP (4357)
Email: support@residentialgroup.com.au

